

UV Water Treatment

UV Disinfection



Ultra Violet (UV) technology is an effective chemical-free technology for water disinfection: Optimum hydraulic design for uniform treatment ; Version built to cGMP requirements available for pharmaceutical and sanitary applications.

Capacity:
up to **116 m³/hr** for disinfection
up to **38 m³/hr** for deozoneisation

Features & benefits:

- Compact, easy to install ; can be mounted horizontally or vertically depending the models
- Conveniently fit into existing pipework
- Easy to maintain and operate
- Low operation cost
- Silent operation
- Chemical-free process ; safety
- Environmentally-friendly: No production of toxic by-products
- Typical lamp operating life of up to 16,000 hours
- No effect on pH, colour, flavour or aroma
- No detrimental effect on product stability
- No residue
- Overdosing not possible
- UV Chamber in 316L stainless steel construction
- Quick replacement of Arc Tubes

Applications

- Production of Ultra-pure water
- Pharmaceutical
- Cosmetics and toiletries industry
- Electronics and semiconductor industry
- General industries
- Destruction of residual ozone after disinfection and sanitisation (deozoneisation)

Related services

Local after-sales service and support teams offer preventative and corrective maintenance programs to ensure the long-term, efficient operation of installed plant.

UV Water Treatment

Specifications

Model	Max Flow m ³ /hr		Power W		Dia mm	Length mm +/- 5mm	Weight kg		Connections T - BSPT F - PN16 Flange TC - Triclamp	
	A	B	Lamp	Total			Empty	Full	Industrial	Pharma
UV 26	2.6	0.9	80	105	63	920	4.5	6	1" T	1" TC
UV 63	6.3	2.0	80	105	102	958	7	12.5	1½" T	1½" TC
UV 135	13.5	4.5	125	140	102	1388	9	17.5	2" T	2" TC
UV 265	26.5	8.7	270	305	102	1388	9	17.5	2" T	2" TC
UV 510	51	16.8	270	305	168	1437	24	51	3" F	3" TC
UV 1160	116	38	500	555	204	1980	46	107	6" F	6" TC

A – Disinfection at 30mJ/cm², 98% T10 transmittance at the end of lamp life

B – Deozonisation at 90mJ/cm², 98% T10 transmittance at the end of lamp life

UV Chamber Specifications

Material	AISI 316L : DN 1.4404	Water Temperature	+5 to +40°C
Finish	Passivated & Electropolished	Maximum CIP Temperature	95°C
Protection	IP65 / NEMA 4	Average Internal Finish (Industrial)	1.0µm Ra
Max. Operating Pressure	10 bar	Average Internal Finish (Pharma)	0.5µm Ra
Mounting	Horizontal or Vertical*		

* Note UV1160 cannot be mounted vertically.

UV Lamp Specifications

Long life 254Nm amalgam lamp.

Lamp Life – Expected 16,000 hours **Warranty** 9,000 hours. Based on less than 4 start/stop cycles per 24 hours.

Documentation

All units are supplied with a Certificate of Conformity.

Pharma units are additionally supplied with material certificates and lamp output certificates.

Control Box Specifications

Enclosure Material	Powder Coated Carbon Steel
Power Supply	230V 50/60Hz
Cable	5m maximum Control Box to UV Chamber
Ambient	+5 to +40°C
Indicator Lamps	Lamp On + Fault
Output (VFC)	Lamp On

UV 26 – UV 510	IP65 / NEMA 4
Dimensions/Weight	400 x 300 x 155 mm (excl Brackets) 15kg
UV1160	IP55 / NEMA12
Dimensions/Weight	600 x 400 x 210 mm (excl Brackets) 19kg

Sydney
Unit 2, 5 Stanton Road
Seven Hills NSW 2147
Ph: + 61 2 8824 0200
Fax: + 61 2 8824 0201

Melbourne
341 Fitzgerald Road
Derrimut VIC 3030
Ph: +61 3 9369 1555
Fax: +61 3 9369 5054

Perth
124 Kewdale Road
Kewdale WA 6105
Ph: + 61 8 9449 1700
Fax: + 61 8 9353 4689

Brisbane
5/26 Navigator Place
Hendra QLD 4011
Ph: +61 7 3268 5990
Fax: +61 7 3268 5993

Adelaide
500 Churchill Road
Kilburn SA 5084
Ph: +61 8 8168 0500
Fax: +61 8 8168 0599

Darwin
5 Dennis Court
Berrimah NT 0828
Ph: +61 8 8947 8931
Fax: +61 8 8947 3310

New Zealand
Level 3, 149-155 Parnell Rd
Parnell, Auckland 1052
Ph: + 64 9 354 4174
Fax: + 64 9 354 4175
nzsales@veoliawater.com

Veolia Water Solutions & Technologies Australia - Head Office

Level 4, Bay Centre, 65 Pirrama Road
Pyrmont NSW 2009 – Australia
Ph. + 61 2 8572 0400 / Fax + 61 2 8572 0410
systems@veoliawater.com

In keeping with the progressive nature of the company, we reserve the right to amend details without notice.

VWS CATALOGUE/UV Water Treatment/ AQF060_EN_V1.1



Visit our websites:
www.veoliawaterst.com.au
www.veoliawaterst.co.nz

Solutions & Technologies